



183 Frobisher Dr. Waterloo, Ontario · N2V 2G4
Tel: (519) 747-2227 · Fax: (519) 747-9613 www.gws ltd.ca

Frozen Coolers

- Pull the electrical plug out for 24 hours, then plug back in. (This allows it to thaw)
- There is a THERMOSTAT setting on the back of the cooler. A small screwdriver can be used. Turn it COUNTER CLOCKWISE until it will not turn. Then turn it CLOCKWISE until you hear it cut in.
- If the water is not cool enough after this procedure, move the THERMOSTAT screw CLOCKWISE in TINY INCREMENTS until you reach the desired coolness.
- If any of the above does not produce proper results, contact our office.